

Attachment 2.3


Scope of Plan Zones for Fitzroy River

Zones that apply to the Fitzroy River

Zone	AMTD (km)	Description
Fitzroy A	59.6 - 115.0	Fitzroy Barrage to Upstream limit of Fitzroy Barrage
Fitzroy B	115.0 - 141.2	Upstream limit of Fitzroy Barrage to Eden Bann Weir
Fitzroy C	141.2 - 183.4	Eden Bann Weir to Upstream limit of Eden Bann Weir
Fitzroy D	183.4 - 276.0	Upstream limit of Eden Bann Weir to Riverslea Gauging Station (GS 130003B)
Fitzroy E	276.0 - 310.3	Riverslea Gauging Station (GS 130003B) to Dawson River junction


- a) Zones are also depicted on the following sheet maps.
- b) AMTD - the Adopted Middle Thread Distance (AMTD) is the distance in kilometres along the middle of a stream from its mouth or junction with the main river.
- c) Upstream limit – the upstream limit of an instream storage is the adopted upstream extent of the storage.
- d) Each zone includes those sections of tributaries where there is access to flow or pondage from the Fitzroy River.

Zones: Fitzroy A, B




Sheet No 1

Zones: Fitzroy B, C, D



Sheet No 2

Zones: Fitzroy D, E



Sheet No 3